



ACUDA II

50182**SILVER****50183****BLACK**WWW.AGURI.EU**x1****50644****x1****50525****x2**

LIT Pritvirtinimo instrukcijos
PL Instrukcja montażu
CZ Návod na montáž
SK Návod na montáž
SLO Navodila za pritrdjevanje
HR Uputa za sastavljanje
HU A felszerelés módja
GR Οδηγίες συναρμολόγησης
UA Інструкція з монтажу
BY Інструкцыя па мантажы
RO Instrucțiuni de montare
TK Uydurma talimat
N Monteringsveiledning


I Istruzioni per il montaggio
GB Fitting instructions
F Instructions de montage
D Montageanleitung
E Instrucciones de montaje
NL Montage-instructies
DK Monteringsinstruktion
FIN Asennusohje
S Monteringsanvisning
RU Инструкция по установке
PT Instruções de Montagem
EST Paigaldusjuhend
LAT Stiprināšanas instrukcija

INSTALLATION




FRONT


1.




2.



3.



4.




REAR


1.




2.






3.



4.









3.







OPTION I
 $X < 112$ cm
 (R)










OPTION II
 $X < 112$ cm
 (L)



OPTION III
 $X > 112$ cm





should not be modified
sollte nicht geändert werden
by neměl být modifikován
не модифицировать
ne doit pas être modifié

